KODAK PROFESSIONAL HC-110 Developer



KODAK PROFESSIONAL HC-110 Developer is a highly concentrated liquid developer. It is intended for use with a variety of black-and-white films, some graphic-arts films, and some glass plates.

It can be used for replenished and non-replenished systems. Use KODAK PROFESSIONAL HC-110 Developer Replenisher to replenish.

FEATURES	BENEFITS
Highly active	Short development times
Liquid concentrate	Easy mixing
Clean solution	Cleaner tanks, racks, and reels; less equipment maintenance
Long solution life	Fewer chemical dumps; less waste
Stable solutions	Easy process control, even with low utilization
Quality of stock solutions maintained over a long time	Good shelf life

PREPARING WORKING SOLUTIONS

You can prepare HC-110 Developer working solutions by diluting stock solution or concentrate. (Both mixing methods provide the same photographic characteristics.)

To prepare stock solution, dilute one part concentrate with three parts water. To prepare working solutions, dilute stock solution or concentrate according to the following tables. Mix either stock or working solutions at a temperature between 10 and 32° C (50 and 90° F).

Take care when measuring the concentrate, because of its viscosity. Follow these recommendations for handling.

- Pour the concentrate slowly to avoid air bubbles. If air bubbles form, wait for them to dissipate before measuring the concentrate.
- Wait for the concentrate to run down the sides of the measuring container. (The concentrate will adhere to the sides of a graduated cylinder.)
- When measuring small amounts of concentrate, use a graduated cylinder accurate to 0.5 millilitre. (To simplify measuring small amounts, use a positive-displacement method such as a syringe.)
- Rinse the measuring container with water at least five times, and pour each rinse into the mixing container.
 This ensures that all the concentrate is dissolved in the water.
- Mix the solution for several minutes until the concentrate is fully dissolved.



<u>❤️③</u> Caution

KODAK PROFESSIONAL HC-110 Developer is a highly concentrated liquid that you must dilute before use. The following tables provide dilution instructions on preparing working solutions from **either** stock solution **or** concentrate. *Exercise caution when following the mixing instructions in the tables, being certain not to intermingle their data.* Follow normal safety precautions whenever working with chemicals to avoid possible physical harm.

	PREPARII	NG WORKING SOLUTIONS I	FROM STOCK SOLUTION*	
To Mix Wo	orking Solution Amount	Add This Amount of Stock Solution [†]	To This Amount of Water†	Ratio of Stock Solution to Water
А	300 mL 500 mL 1 qt 1 L 5 L 7.6 L (2 gal) 18.9 L (5 gal)	75 mL 125 mL 236 mL (8 fl oz) 250 mL 1.25 L 1.9 L (2 qt) 4.73 L (5 qt)	225 mL 375 mL 708 mL (24 fl oz) 750 mL 3.75 L 5.7 L (6 qt) 14.17 L (15 qt)	1:3
В	300 mL 500 mL 1 qt 1 L 5 L 7.6 L (2 gal) 18.9 L (5 gal)	38 mL 63 mL 118 mL (4 fl oz) 125 mL 625 mL 950 mL (1 qt) 2.36 L (2.5 qt)	262 mL 437 mL 826 mL (28 fl oz) 875 mL 4.38 mL 6.65 L (7 qt) 16.54 L (17.5 qt)	1:7
С	7.6 L (2 gal) 18.9 L (5 gal)	1.54 L (52 fl oz) 3.78 L (4 qt)	6.08 L (6 qt 13 fl oz) 15.12 L (16 qt)	1:4
D	7.6 L (2 gal) 18.9 L (5 gal)	770 mL (26 fl oz) 1.89 L (2 qt)	6.84 L (7 qt 6 fl oz) 17.01 L (18 qt)	1:9
E	7.6 L (2 gal) 18.9 L (5 gal)	630 mL (21 fl oz) 1.58 L (1 qt 11 fl oz)	6.97 L (7 qt 11 fl oz) 17.32 L (18 qt 21 fl oz)	1:11
F	7.6 L (2 gal) 18.9 L (5 gal)	380 mL (13 fl oz) 950 mL (1 qt)	7.22 L (7 qt 19 fl oz) 17.95 L (19 qt)	1:19

^{*} **IMPORTANT NOTE:** Due to the high viscosity of the developer concentrate, it is preferable to dilute it to a *stock solution*. This may be a more convenient way to store the chemical for future preparation into a *working solution*, per the above instructions.

[†] Due to rounding of decimals, slight variations occur when amounts are given in millilitres and fluid ounces.

	PREPARI	NG WORKING SOLUTIONS	FROM CONCENTRATE*		
	orking Solution	Add This Amount of Concentrate	To This Amount of	Ratio of Concentrate	
Dilution	Amount	Concentrate	Water [†]	to Water	
	300 mL	19 mL	281 mL		
	500 mL	31 mL	469 mL		
	1 qt	59 mL (2 fl oz)	885 mL (30 fl oz)		
Α	1 L	63 mL	937 mL	1:15	
	5 L	313 L	4687 mL		
	7.6 L (2 gal)	473 mL (16 fl oz)	7.1 L (7.5 qt)		
	13.3 L (3.5 gal)	828 L (28 fl oz)	12.5 L (13 qt 4 fl oz)		
	300 mL	9 mL	291 mL		
	500 mL	16 mL	484 mL		
	1 qt	30 mL (1 fl oz)	914 mL (31 fl oz)		
В	1 L	31 mL	969 mL	1:31	
	5 L	156 mL	4844 mL		
	15.2 L (4 gal)	473 mL (16 fl oz)	14.7 L (15.5 qt)		
	26.6 L (7 gal)	828 mL (28 fl oz)	25.75 L (27 qt 4 fl oz)		
С	9.5 L (2.5 gal)	473 mL (16 fl oz)	9 L (9.5 qt)	1:19	
C	16.6 L (17.5 gal)	828 mL (28 fl oz)	15.75 L (16 qt 20 fl oz)	1.19	
D	18.9 L (5 gal)	473 mL (16 fl oz)	18.4 L (19.5 qt)	1:39	
U	33.3 L (8 gal 3 qt)	828 mL (28 fl oz)	32.5 L (34 qt 4 fl oz)	1.39	
E	22.7 L (6 gal)	473 mL (16 fl oz)	22.2 L (23.5 qt)	1:47	
E	39.8 L (10.5 gal)	828 mL (28 fl oz)	39 L (41 qt 4 fl oz)	1:47	
F	37.9 L (10 gal)	473 mL (16 fl oz)	37.4 L (39.5 qt)	4.70	
F	66.3 L (17.5 gal)	828 mL (28 fl oz)	65.5 L (69 qt 4 fl oz)	1:79	

^{*} **IMPORTANT NOTE:** The above instructions refer to the dilution of the package contents from the manufacturer (the *developer concentrate*), directly to a working solution, *without* use of an intermediate stock solution.

[†] Due to rounding of decimals, slight variations occur when amounts are given in millilitres and fluid ounces.

DEVELOPMENT TIMES

If film is properly exposed, the times in the following tables should produce negatives with contrast suitable for printing with a diffusion enlarger (or by contact) on a normal-contrast black-and-white paper. If printing negatives with a condenser enlarger, decrease the development time by approximately 30 percent to produce lower contrast.

For critical applications, run tests to determine the best development time. If your negatives are consistently too dense or high in contrast, decrease the development time; if they're too thin or low in contrast, increase the development time.

The following tables offer starting-point recommendations. Adjust as needed.

DEV	ELOPME	NT TIME	S FOR A	ODAK S	HEET FI	LMS				
	Development Time (Minutes)									
KODAK Film	Tray* Continuous Agitation					Large Tank† Manual Agitation at 1-Minute Intervals				
	18°C (65°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	18°C (65°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)
DILUTION A	1									
EKTAPAN / EKP‡	3 1/4	3	2 3/4	2 1/2	2 1/4	4	3 ¾	3 1/4	3	2 3/4
DILUTION B	1									
Commercial‡	2 3/4	2 1/4	2 1/4	2	1 3⁄4	_	_	_	_	_
EKTAPAN / EKP‡	5	4 1/2	4 1/4	4	3 1/2	7	6	5 1/2	5	4 1/4
PLUS-X Pan Professional / PXT‡	6	5	4 3/4	4 1/2	4	8	7	6 1/2	6	5 ½
Technical Pan / TP								varying c ODAK Te		
T-MAX 100 Professional / TMX	8 1/2	7 1/2	7	6 1/2	5 1/2	11 ½	9 1/2	8 1/2	7 1/2	7
PROFESSIONAL T-MAX 100	6 1/4	5 1/2	4 3/4	4 1/2	3 3/4	7 1/2	6 ½	6	5 1/4	4 1/2
T-MAX 400 Professional and PROFESSIONAL T-MAX 400	9	7 ½	7	6 ½	6	10	8 ½	7 ½	7	6 ½
TRI-X Pan Professional / TXT‡	6	5 1/2	5	41/2	4	8	7 1/2	7	6	5
PROFESSIONAL TRI-X 320 Film / 320TXP	3 3/4	3 1/4	3	2 3/4	2 1/2	4 3/4	4 1/4	4	3 1/2	3

^{*} Prewet the film in *clean* water at 20°C (68°F) for 1 to 2 minutes with agitation. Each sheet should be thoroughly wet to prevent sticking (of sheets) and promote even development.

[†] Tank-development times shorter than 5 minutes may produce unsatisfactory uniformity.

[‡] Tray development times also apply to tank development using gaseous-burst agitation. Set the burst duration for 1 second with 10 seconds between bursts; provide sufficient pressure to increase the solution level 16 mm (5% inch).

DEV	'ELOPME	ENT TIME	ES FOR	KODAK	ROLL FIL	MS				
				Devel	opment '	Time (Mi	nutes)			
KODAK Film	Small Tank* Manual Agitation at 30-Second Intervals				Large Tank† Manual Agitation at 1-Minute Intervals					
	18°C (65°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	18°C (65°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)
DILUTION A		I	I	l .	l.	l .	I	1		
Recording 2475	5 ½	4 1/2	4	3 ½	3			NR		
TRI-X Pan / TX	4 1/4	3 3/4	3 1/4	3	2 1/2	4 3/4	4 1/4	4	3 3/4	3 1/4
TRI-X Pan Professional / TXP			NR			3 1/2	3	3	2 3/4	2 1/4
DILUTION B										
PLUS-X Pan / PX PLUS-X Pan Professional / PXP‡	6	5	4 ½	4	3 ½	6 ½	5 ½	5	4 3/4	4
PROFESSIONAL PLUS-X 125	4	3 1/2	3	2 3/4	2 1/2	4 1/2	3 3/4	3 ½	3 1/4	2 3/4
Recording 2475	11	9	8	7	6	NR				
Technical Pan / TP				ping KOD ee KODA						
T-MAX 100 Professional / TMX	8	7	6 1/2	6	5	8 1/2	7 1/2	7	6 1/2	5 ½
PROFESSIONAL T-MAX 100	6 1/2	6	5 1/2	5	4	7 1/2	6 1/2	6	5 1/4	4 1/2
T-MAX 400 Professional and PROFESSIONAL T-MAX 400	6 ½	6	5 ½	5	4 ½	8	7	6 ½	6	5
T-MAX P3200 Professional / TMZ					th t	bloo bolo				I.
PROFESSIONAL T-MAX P3200	1			5	ee ine ia	bles belo	w.			
TRI-X Pan / TX	8 1/2	7 1/2	6 1/2	6	5	9 1/2	8 1/2	8	7 ½	6 ½
TRI-X Pan Professional / TXP	5 3/4	5 1/2	5 1/4	4 3/4	3 3/4	7	6 1/4	6	5 ½	5
PROFFESSIONAL TRI-X 400 Film / 400TX	4 1/2	3 3/4	3 ½	3	2 1/2	5	4 1/2	4	3 ½	3
PROFESSIONAL TRI-X 320 Film / 320TXP	5 1/4	4 3/4	4 1/4	4	3 1/2	6 1/4	5 ½	5	4 1/2	4
VERICHROME Pan / VP	6	5	4 1/2	4	2	8	6 ½	6	5 ½	4 1/2

Note: Tank-development times shorter than 5 minutes may produce unsatisfactory uniformity.

^{*} Development on a reel in a small roll-film tank.

† Development of several reels in a basket.

‡ Development times also apply to tank development using gaseous-burst agitation. Set the burst duration for 1 second with 10 seconds between bursts; provide sufficient pressure to increase the solution level 16 mm (5/8 inch).

NR = Not recommended

VELOPMENT T	ELOPMENT TIMES FOR <i>KODAK T-MAX</i> P3200 PROFESSIONAL ROLL FILMS											
Dilution D		Development Time (Minutes)										
Dilution B	Small Tank*							Rotary	Tube†			
Exposed at El	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	27°F (80°F)	29°F (85°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	27°F (80°F)	29°F (85°F)
400 / 27°	7 ½	6 1/2	5 ½	5	4 1/2	3 1/2	7	6 1/4	5 3/4	5	4 1/4	3 1/4
800 / 30°	8	7	6	5 1/2	4 3/4	4	8	7	6	5 1/4	4 1/2	3 1/2
1600 / 33°	9	7 1/2	6 1/2	6	5	4 1/2	8 3⁄4	7 1/2	6 1/2	5 3/4	4 3/4	3 3/4
3200 / 36°	11 ½	10	8 ½	7 1/2	6 1/2	5 3⁄4	11 ½	10	8 1/2	7 1/2	6 1/2	5
6400 / 39°	14	12	10 ½	9 1/2	8	6 3⁄4	13	11 ½	10	9	8	6

^{*} Development on a reel, in a small roll-film tank, with manual agitation at 30-second intervals.

Note: Tank-development times shorter than 5 minutes may produce unsatisfactory uniformity.

Dilution B					Deve	lopment [*]	Time (Mir	iutes)				
Dilution B	Small Tank*								Rotary	Tube†		
Exposed at El	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	27°F (80°F)	29°F (85°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)	27°F (80°F)	29°F (85°F)
400 / 27°	7 1/2	6 1/2	5 ½	5	4 1/4	3 3/4	7 1/2	6 ½	5 1/2	5	4 1/4	3 3/4
800 / 30°	8 1/2	7 1/4	6 1/4	5 3/4	4 3/4	4 1/4	8 1/2	7 1/4	6 1/4	5 3/4	4 3/4	4 1/4
1600 / 33°	9 1/4	8	6 3⁄4	6 1/4	5 1/4	4 1/2	9 1/4	8	6 3⁄4	6 1/4	5 1/4	4 1/2
3200 / 36°	10 ½	9	7 3⁄4	7	6	5 1/4	10 ½	9	7 3/4	7	6	5 1/4
6400 / 39°	12	10 1/4	8 3⁄4	8	6 3⁄4	5 3/4	12	10 1/4	8 3/4	8	6 3⁄4	5 3/4

^{*} Development on a reel, in a small roll-film tank, with manual agitation at 30-second intervals.

Note: Tank-development times shorter than 5 minutes may produce unsatisfactory uniformity.

[†] Development in a rotary-tube processor with continuous agitation.

[†] Development in a rotary-tube processor with continuous agitation.

DEVELOPMENT TIMES FOR KODAK FILMS IN ROTARY TUBES								
KODAK Film	Development Time (Minutes)* Dilution B							
KODAK FIIM	18°C (65°F)	20°C (68°F)	21°C (70°F)	22°C (72°F)	24°F (75°F)			
ROLL FILM	·	11	I	I	I			
T-MAX 100 Professional / TMX	_	6 ½	6	5 ½	4 1/2			
PROFESSIONAL T-MAX 100	7	5 3⁄4	5 1/4	4 3/4	4			
T-MAX 400 Professional and PROFESSIONAL T-MAX 400	_	6	5 ½	5	5			
TRI-X Pan / TX	7	6	5 ½	4 1/2	4			
TRI-X Pan Professional / TXP	_	8 1/2	8	6 1/2	5			
PROFESSIONAL TRI-X 400 Film / 400TX	4 1/2	3 3/4	3 ½	3	2 1/2			
PROFESSIONAL TRI-X 320 Film / 320TXP	5 1/4	4 3/4	4 1/4	4	3 1/2			
PLUS-X / PX	8	7	6	5	4			
PROFESSIONAL PLUS-X 125	4	3 ½	3	2 3/4	2 1/2			
SHEET FILM								
T-MAX 100 Professional / TMX	_	6 1/2	6	5 ½	4 1/2			
PROFESSIONAL T-MAX 100	7	5 3/4	5 1/4	4 3/4	4			
T-MAX 400 Professional and PROFESSIONAL T-MAX 400	_	6	5 ½	5	5			
PROFESSIONAL TRI-X 320 Film / 320TXP	3 1/4	3	2 3/4	2 1/2	2 1/4			

^{*} Development in a rotary-tube processor with continuous agitation.

KODAK Film	Application	Dilution	Development Time (Minutes) at 20°C (68°F)*				
	Conving photographs	В		2	1/4		
Commercial	Copying photographs	D		4	1/2		
	Gravure	С	3				
Professional Copy	Copying photographs	Е	4				
Separation		С	Printer				
Negative 4131,	Color-separation negatives made from masked transparencies		Cyan	Magenta	Yellow	Black	
Type 1	nom masked transparencies		4	3 1/2	4	3	
				Printer	Masks		
Pan Masking	Camera-back masking	Е	Cyan	Magenta	Yellow	Black	
4570			4	4	4	_	
	Transparency masking	D	3 1/4	3 1/4	3 1/4	3 1/4	

^{*} Development in a tray with continuous agitation.

REPLENISHMENT

General

Replenish tank solutions of HC-110 Developer with a solution made from KODAK PROFESSIONAL HC-110 Developer Replenisher. To prepare a replenisher stock solution, pour the contents (16 ounces [473 mL]) of the replenisher concentrate into a mixing container that holds at least 3.8 litres (1 gallon). Add enough water to bring the total volume to 3.8 litres (1 gallon). Stir the solution until it is uniform. You can store the replenisher stock solution at 18 to 24°C (65 to 75°F) for up to 6 months in a full, tightly closed bottle, or up to 2 months in a half-full, tightly closed bottle.

When ready to replenish the tank solution, prepare replenisher working solution by diluting the replenisher stock solution with water according to the table below.

PREPARING REPLENISHER SOLUTIONS									
For This Dilution of Developer Working Solution	Add This Amount of Replenisher Stock Solution	To This Amount of Water							
Α	1 part	none							
В	2 parts	1 part							
С	1 part	none							
D	1 part	1 part							
Е	8 parts	11 parts							
F	_	_							

Note: Dilution F is very dilute; we do not recommend replenishing this solution.

Replenishment Rate

Add 22 mL (¾ fluid ounce) of replenisher solution for each 20.3 x 25.4 cm (8 x 10-inch) sheet, 135-36 roll, or 120 roll (or equivalent) processed. Stir or recirculate the solution thoroughly after each addition. With an average drain time of 10 seconds between the developer and the stop bath, this amount of replenisher will usually match the carry-out of developer. However, if more solution is carried out than replaced, add fresh developer *working solution* (of the appropriate dilution) to make up the difference.

Note: If negatives become too thin or low in contrast, increase the replenishment rate; if they become too dense or high in contrast, decrease the replenishment rate.

When you aren't processing film, cover the tanks with floating lids to minimize oxidation.

Process Control

When replenishing tank solutions, monitor the developer activity with KODAK Black-and-White Process Control Strips. Depending on the utilization, you can use a tank solution for up to one month if the control strips indicate proper developer activity.

If you don't use control strips, discard the tank solution when you have —

- Replenished the solution for two weeks;
- Added an amount of replenisher that equals the original volume of the working solution; or
- Processed fifty 20.3 x 25.4 cm sheets per litre (two hundred 8 x 10-inch sheets [or equivalent] per gallon) of developer.

Capacity

Discard the developer after processing the number of sheets (or equivalent) listed below.

	CAPACITY OF DEVELOPER WORKING SOLUTIONS									
	Tray			without nishment						
Dilution	8 x 10-in. Sheets per Gallon	20.3 x 25.4 cm Sheets per Litre	8 x 10-in. Sheets per Gallon	20.3 x 25.4 cm Sheets per Litre						
Α	20	5	40	10						
В	10	2.5	20	5						
С	15	4	30	8						
D	8	2	15	4						
Е	5	1.5	10	3						
F	2	1	NR	NR						

NR = Not recommended

STORAGE LIFE

The table below provides guidelines for storing unused solutions at 18 to 24°C (65 to 75°F). The *storage temperature is important* as higher temperatures cause solutions to oxidize rapidly.

STORAGE LIFE (MONTHS) OF UNUSED SOLUTIONS*									
Solution	Full, Tightly Closed Bottle	ightly Closed Tightly Closed							
Developer	1								
Stock Solution	6	2	2						
Working Solution— Dilution A	6	2	2						
Dilution B	3	1	1						
Dilution C	6	2	2						
Dilution D	3	1	1						
Dilution E	2	1	1						
Dilution F	NR	NR	NR						
Replenisher	Replenisher								
Stock Solution	6	2	2						

^{*} Stored at 18 to 24°C (65 to 75°F). NR = Not recommended

MORE INFORMATION

Kodak has many publications to assist you with information on Kodak products, equipment, and materials.

The following publications are available from dealers who sell Kodak products, or you can contact Kodak in your country for more information.

E103CF	Chemicals for KODAK PROFESSIONAL Black-and-White Films
F-7	KODAK VERICHROME Pan Film
F-8	KODAK PLUS-X Pan and KODAK PLUS-X Pan Professional Films
F-9	KODAK TRI-X Pan and KODAK TRI-X Pan Professional Films
F-10	KODAK EKTAPAN Film
F-16	KODAK Commercial Film
F-32	KODAK T-MAX Professional Films
F-4016	KODAK PROFESSIONAL T-MAX Films
F-4017	KODAK PROFESSIONAL TRI-X 320 and 400 Films
F-4018	KODAK PROFESSIONAL PLUS-X 125 Film
P-255	KODAK PROFESSIONAL Technical Pan Films

Note: The Kodak materials described in this publication for use with KODAK HC-110 Developer Replenisher are available from dealers who supply Kodak Professional products. You can use other materials, but you may not obtain similar results.

For the latest version of technical support publications for KODAK PROFESSIONAL Products, visit Kodak on-line at:

http://www.kodak.com/go/professional

If you have questions about KODAK PROFESSIONAL Products, call Kodak.

In the U.S.A.:

1-800-242-2424, Ext. 19, Monday–Friday
9 a.m.–7 p.m. (Eastern time)

In Canada:

1-800-465-6325, Monday–Friday 8 a.m.–5 p.m. (Eastern time)



